

PANEL JACKET SPECIFICATIONS

	CHEST (+/- 1")		SLEEVE LENGTH +/- 1/2"		BACK LENGTH +/- 1"	
SIZE	REGULAR	LONG	REGULAR	LONG	REGULAR	LONG
XS	38.5 - 40	38.5 - 40				
SMALL	42.5 - 44	42.5 - 44	34 3/4	36 1/4	29 1/4	31 1/4
MEDIUM	46.5 - 48	46.5 - 48	35	36 1/2	29 3/8	31 3/8
LARGE	50.5 - 52	50.5 - 52	35 1/4	36 3/4	29 1/2	31 1/2
XL	54.5 - 56	54.5 - 56	36 1/8	37 5/8	29 5/8	31 5/8
2XL	58.5 - 60	58.5 - 60	37 1/8	38 5/8	30 1/4	32 1/4
3XL	62.5 - 64	62.5 - 64	37 1/2	39	30 1/4	32 1/4
4XL	66.5 - 68	66.5 - 68	38 1/2	40	30 1/4	32 1/4
5XL	70.5 - 72	70.5 - 72	39	40 1/2	30 1/4	32 1/4
6XL	74.5 - 76	74.5 - 76	39 1/2	41	30 1/4	32 1/4

HOW TO MEASURE

CHEST: Measure entirely around the largest part of the chest.

SLEEVE: Measure from the **CENTER BACK** of the neck to the wrist.

BACK LENGTH: From the back, measure from the base of the neck downward.

All measurements are in inches.