

EISENHOWER PATCH JACKET SPECIFICATIONS

SIZE	CHEST (+/- 1")		SLEEVE LENGTH +/- 1/2"		BACK LENGTH +/- 1"	
	Reg	Long	Reg	Long	Reg	Long
XS	38.5 - 40	38.5 - 40				
SMALL	42.5 - 44	42.5 - 44	34 1/4	36 1/2	26 1/2	28
MEDIUM	46.5 - 48	46.5 - 48	35	37	26 3/4	28 1/4
LARGE	50.5 - 52	50.5 - 52	35 1/2	37 1/2	27 1/2	29
XL	54.5 - 56	54.5 - 56	36 1/8	38 1/8	27 1/2	29
2XL	58.5 - 60	58.5 - 60	37	39	28 1/2	30
3XL	62.5 - 64	62.5 - 64	37 1/2	39 1/2	28 5/8	30 1/8
4XL	66.5 - 68	66.5 - 68	38 1/4	40 1/4	29 1/2	31
5XL	70.5 - 72	70.5 - 72	38 3/4	40 3/4	29 7/8	31 1/8

HOW TO MEASURE

CHEST: Measure entirely around the largest part of the chest.

SLEEVE: Measure from the **CENTER BACK** of the neck to the wrist

BACK LENGTH: From the back, measure from the base of the neck downward.

All measurements are in inches.